


normcore

POCKET COFFEE SCALE

MAX:2000g / Min:0.1g / Battery: 800mAh / Charging mode: 5V / 1A adapter



Mode indicator: Indicates that "E" Espresso Auto Timing, "M" Brewing Manual Timing, "P" Brewing Auto Timing is currently on.

Sound indicator: the indicator light is on, indicating that the sound is on.

At the same time, press and hold "T" to turn on/off the sound prompt.

Battery indicator: indicates the current power. Please charge in time if the power is insufficient.

Charging display: " " flashing display when charging, " " long bright display when fully charged.

Lack of power display: " " blinking display, until no power display "LO" off.

Unit indicator: indicates that the current opening is oz/ml/g.

Automatic sleep: the current state is still, and the weight and time have not changed. After 10 minutes, it will automatically sleep.

Automatic wake-up: when the weight changes 100g in the sleep state, the electronic scale will start automatically.

Precautions

The coffee scale needs to be used on a static horizontal plane. The parts of the coffee scale are precise. Do not collide vigorously.

Do not use the fast charging function power supply to charge

Do not use this product during charging. The coffee scale is not waterproof.

Do not wash and keep the charging port dry. The maximum weight of the coffee scale is 2000g.

Do not weigh too heavy objects to cause damage.

The surface temperature of the product is -10 °C to 60 °C. After placing the insulation pad, -20 °C to 100 °C.

The internal structure of the equipment is precise, and unauthorized disassembly is prohibited.

The warranty period for this equipment is one year. Unauthorized disassembly or artificial damage is not covered by the warranty.

If the violation of the above precautions leads to product damage, misalignment, and other adverse consequences, our company will not bear the relevant responsibilities.

normcore

Press and hold the " " timing key to select the desired mode. Switch in sequence according to "E" Espresso Auto Timing, "M" Brewing Manual Timing, "P" Brewing Auto Timing.

"E" Espresso Auto Timing



Place the coffee scale on the tray of the espresso machine, turn on the coffee scale, place the coffee cup on the coffee scale and then it will automatically tare.



Turn on the espresso machine. When the coffee drops into the cup, the coffee scale starts to calculate the weight and automatically counts. After the drip is over, the timing and weighing stop. Once remove the cup, the coffee scale will return to the initial state ready for the next brew.

"M" Brewing Manual Timing



Turn on the coffee scale, put the pour over maker on the scale. After soaking the coffee filter paper, proceed to press the "T" tare button briefly.



Add the fresh ground and pay attention to the specific weighing value at the same time.



Briefly press the "T" tare button, and the weight will be cleared. Prepare for coffee brewing: Briefly press the " " timing key to start the timing function to help you better control the time of brewing and water injection.



After brewing, press the " " timing key briefly to stop the timing, and the coffee scale will accurately display the brewing data for you.

"P" Brewing Auto Timing



Turn on the coffee scale, put the pour over maker on the scale. After soaking the coffee filter paper, proceed to press the "T" tare button briefly.



Add the fresh ground and pay attention to the specific weighing value at the same time.



Briefly press the " " timing key, and the coffee scale will automatically enter the timing/weighing state when it counts down to "3, 2, and 1". It is ready for coffee brewing: When the water is injected, the timing and weighing will run automatically.



After brewing, take away the coffee appliance, and the coffee scale will accurately display the brewing data for you. Double-click "T" to return to the initial state for the next brewing.